



# EZ4005 Ammonium Analyser

Продукт №: EZ4005.XXXXXXX

BGN Цена: Свържете се с нас

## Online automatic titration of Ammonium in water

EZ4000 Series Analysers are single-parameter titrators that achieve excellent precision and accuracy. Depending on the parameter of interest, the measuring range and the water matrix the EZ4000 Series may use either potentiometry i.e. acid-base, redox or precipitation titration, where the endpoint is determined by a change in a specific variable, or photocolorimetry, where colour change is used to determine the endpoint of the titration. The high precision dispenser for addition, robust peristaltic pumps for sampling and drain, and carefully designed liquid pathways all add up to the highest performance for industrial and environmental analysis needs.

#### Results you can rely on

Smart automatic features for validation, priming and cleaning are embedded in the controller software and contribute to analytical performance, maximised uptime and negligible operator invervention. Sample lines and analysis vessel are cleaned with demineralised water to eliminate cross contamination between samples. Electronic and wet-chemical part of the analyser are strictly separated. A transparent door allows for instant visual inspection of the wet part.

### Flexibility that meets your needs

EZ Series Ammonium Analysers come in an attractive, ergonomic mainframe with a compact footprint. All hardware is controlled by the integrated industrial panel PC. The modular build allows for the analyser to match your application and operational needs.

- The standard measuring range can be narrowed by a different calibration range or extended via internal dilution options.
- Analogue and digital output options
- Multiple stream analysis for up to 8 sample streams

There are many additional options available. Please contact Hach for more details.

## Спецификации

Demineralised water: For rinsing / dilution

Digital outputs: Optional: Modbus (TCP/IP, RS485)

Earth connection: Dry and clean earth pole with low impedance (< 1 Ohm) using an earth cable of > 2.5 mm<sup>2</sup>

Instrument air: Dry and oil free according to ISA-S7.0.01-1996 quality standard for instrument air

Precision: Better than 2% full scale range for standard test solutions

Reagent Requirements: Keep between 10 - 30 °C

Validation: Automatic; frequency freely programmable

Авариен сигнал: 1 x malfunctioning, 4 x user-configurable, max. 24 VDC/0.5 A, potential free contacts

Аналогови изходи: Active 4 - 20 mA max. 500 Ohm load, standard 1, max. 8 (option)

Бр. потоци проби: 1, 2, 4 or 8 Гаранция: 24 месеца Граница на откриваемост: ≤ 10 mg/L

Дренаж: Atmospheric pressure, vented, min. Ø 32 mm

Захранване: 100 - 240 VAC, 50/60 Hz

Max. power consumption: 120 VA

Измерване метод: Acid-base titration with sulphuric acid, conform with standard method APHA 4500-NH3

Измерване, диапазон:  $100 - 5000 \text{ mg/L NH}_4$ 

Optional:

10 - 500 mg/L NH<sub>4</sub>

25 - 1250 mg/L NH<sub>4</sub>

50 - 2500 mg/L NH<sub>4</sub>

Какво има в кутията: EZ4005 Ammonium Analyser, Instruction Manual, 1 x Double Bit Door Key, 1 x Mounting

Brackets, 1 x pH Electrode, Routine S7 Connection,

1 x empty 5L Reagent Container with Fittings (for H, SO, Solution) and 1 x empty 10L Reagent

Container with Fittings (for NaOH Solution)

Калибриране: N.A.

Клас на защита: Protection class: Analyser cabinet: IP44 / Panel PC: IP65

Кювети за проба: 10 - 15 minutes

Материал: Hinged part: Thermoform ABS, door: PMMA

Wall section: Galvanised steel, powder coated

Модел: ЕZ4005

Околна температура: 10 - 30 °C ±4 °C deviation at 5 - 95% relative humidity (non-condensing)

Параметър: Ammonium

Пауза: 100 - 240 VAC, 50/60 Hz

Проба, дебит: 100 - 300 mL/min

Проба, качество: Maximum particle size 100  $\mu$ m, < 0.1 g/L; Turbidity < 50 NTU

Проба: налягане:By external overflow vesselРазмери (В х Ш х Д):690 мм х 465 мм х 330 ммСертификати:CE compliant / UL certified

Смущения: Soaps, oily matter, suspended solids or precipitates may coat the glass electrode and cause a

sluggish response. Allow additional time between titrant additions to let the electrode come to equilibrium or clean the electrodes occasionally. Alkaline compounds may interfere with the

titration.

Тегло: 25 kg

Температура на проба: 10 - 30 °C

EZ4005 Ammonium Analyser, Instruction Manual, $1 \times 1$ Double Bit Door Key, $1 \times 1$ Mounting Brackets, $1 \times 1$ PH Electrode, Routine S7 Connection, $1 \times 1$ Reagent Container with Fittings (for $1 \times 1$ Ph Solution) and $1 \times 1$ Reagent Container with Fittings (for NaOH Solution)
Product details pdf footer