



## **EZ1031 Phosphate Analyser (Vanadate Yellow Method) PO<sub>4</sub>-P**

Продукт №:

**EZ1031.XXXXXXXXXX**

BGN Цена:

Свържете се с нас

### **Online colorimetric analysis of Phosphate in water (Vanadate Yellow Method)**

EZ1000 Phosphate Analysers achieve excellent precision and accuracy. At the heart of the colorimeter there is a compact photometer assembly developed especially for the EZ Series. Consumption of reagents is reduced by low volume analysis, yet high sensitivity is assured by a long optical path length. The limit of detection is in the low µg/L range.

#### **Results you can rely on**

Smart automatic features for calibration, validation, priming and cleaning are embedded in the controller software and contribute to analytical performance, maximised uptime and negligible operator intervention. Precision micropumps dose all reagents. Sample lines and analysis vessel are cleaned with demineralised water to eliminate cross contamination between samples. Electronic and wet-chemical part of the analyser are strictly separated. A transparent door allows for instant visual inspection of the wet part.

#### **Flexibility that meets your needs**

EZ Series Phosphate Analysers come in an attractive, ergonomic mainframe with a compact footprint. All hardware is controlled by the integrated industrial panel PC. The modular build allows for the analyser to match your application and operational needs.

- The standard measuring range can be narrowed by a different calibration range or extended via internal dilution options.
- Analogue and digital output options
- Multiple stream analysis for up to 8 sample streams

There are many additional options available. Please contact Hach for more details.

---

### **Спецификации**

Demineralised water:	For rinsing / dilution
Digital outputs:	Optional: Modbus (TCP/IP, RS485)
Earth connection:	Dry and clean earth pole with low impedance (< 1 Ohm) using an earth cable of > 2.5 mm <sup>2</sup>
Instrument air:	Dry and oil free according to ISA-S7.0.01-1996 quality standard for instrument air
Precision:	Better than 3% full scale range for standard test solutions
Reagent Requirements:	Keep between 10 - 30 °C
Validation:	Automatic; frequency freely programmable
Аварийен сигнал:	1 x malfunctioning, 4 x user-configurable, max. 24 VDC/0.5 A, potential free contacts

Автоматично почистване:	Да
Аналогови изходи:	Active 4 - 20 mA max. 500 Ohm load, standard 1, max. 8 (option)
Бр. потоци проби:	1, 2, 4, or 8
Гаранция:	24 месеца
Граница на откриваемост:	≤ 20 µg/L
Дренаж:	Atmospheric pressure, vented, min. Ø 32 mm
Захранване:	100 - 240 VAC, 50/60 Hz
	Max. power consumption: 120 VA
Измерване метод:	Colorimetric measurement using vanadate yellow method (450 nm)
Измерване, диапазон:	0.1 - 10 mg/L PO <sub>4</sub> -P
	Optional:
	0.02 - 1 mg/L
	0.05 - 2.5 mg/L
	0.05 - 5 mg/L
	0.8 - 40 mg/L (with internal dilution)
	1.6 - 80 mg/L (with internal dilution)
	10 - 1000 mg/L (with internal dilution)
Какво има в кутията:	EZ1031 Phosphate Analyser, Instruction Manual, 1 x Double Bit Door Key, 1 x Mounting Brackets and 1 x empty 2.5L Reagent Container with Fittings (for Colour Solution)
Калибриране:	Automatic, 2-point; frequency freely programmable
Клас на защита:	Protection class: Analyser cabinet: IP44 / Panel PC: IP65
Кювети за проба:	10 min (dilution + 5 min)
Материал:	Hinged part: Thermoform ABS, door: PMMA
	Wall section: Galvanised steel, powder coated
Модел:	EZ1031
Околна температура:	10 - 30 °C ± 4 °C deviation at 5 - 95% relative humidity (non-condensing)
Параметър:	Orthophosphate (PO <sub>4</sub> -P)
Пауза:	100 - 240 VAC, 50/60 Hz
Проба, дебит:	100 - 300 mL/min
Проба, качество:	Maximum particle size 100 µm, < 0.1 g/L; Turbidity < 50 NTU
Проба: налягане:	By external overflow vessel
Размери (В x Ш x Д):	690 мм x 465 мм x 330 мм
Сертификати:	CE compliant / ETL certified
Смущения:	Positive interference is caused by Silica Arsenate if the sample is heated. Negative interferences are caused by Arsenate, Fluoride, Thorium, Bismuth, Sulphide, Thiosulphate, Thiocyanate or excess of Molybdate. Blue colour is caused by Ferrous Iron but this does not affect results for Ferrous Iron concentrations < 100 mg/L. If Nitric Acid is used, Chloride interferes from 75 mg/L. Large amounts of colour and turbidity interfere. Fats, oil, proteins, surfactants and tar.
Тегло:	25 kg
Температура на проба:	5 - 30 °C

## Какво има в кутията

EZ1031 Phosphate Analyser, Instruction Manual, 1 x Double Bit Door Key, 1 x Mounting Brackets and 1 x empty 2.5L Reagent Container with Fittings (for Colour Solution)