



EZ5010 Calcium Hardness + Total Alkalinity Analyser

Продукт №: EZ5010.XXXXXXXXXX
BGN Цена: Свържете се с нас

Online automatic titration of Calcium Hardness + Total Alkalinity in water

EZ5000 Series Analysers are multi-parameter titrators that achieve excellent precision and accuracy. Depending on the parameter of interest, the measuring range and the water matrix the EZ5000 Series may use either potentiometry i.e. acid-base, redox or precipitation titration, where the endpoint is determined by a change in a specific variable, or photolorimetry, where colour change is used to determine the endpoint of the titration. The high precision dispenser for addition, robust peristaltic pumps for sampling and drain, and carefully designed liquid pathways all add up to the highest performance for industrial and environmental analysis needs.

Results you can rely on

Smart automatic features for validation, priming and cleaning are embedded in the controller software and contribute to analytical performance, maximised uptime and negligible operator intervention. Sample lines and analysis vessel are cleaned with demineralised water to eliminate cross contamination between samples. Electronic and wet-chemical part of the analyser are strictly separated. A transparent door allows for instant visual inspection of the wet part.

Flexibility that meets your needs

EZ Series Alkalinity and Hardness Analysers come in an attractive, ergonomic mainframe with a compact footprint. All hardware is controlled by the integrated industrial panel PC. The modular build allows for the analyser to match your application and operational needs.

- The standard measuring range can be narrowed by a different calibration range or extended via internal dilution options.
- Analogue and digital output options
- Multiple stream analysis for up to 8 sample streams

There are many additional options available. Please contact Hach for more details.

Спецификации

Demineralised water:	For rinsing
Digital outputs:	Optional: Modbus (TCP/IP, RS485)
Earth connection:	Dry and clean earth pole with low impedance ($< 1 \text{ Ohm}$) using an earth cable of $> 2.5 \text{ mm}^2$
Instrument air:	Dry and oil free according to ISA-S7.0.01-1996 quality standard for instrument air
Precision:	Better than 2% full scale range for standard test solutions
Reagent Requirements:	Keep between 10 - 30 °C

Validation:	Automatic; frequency freely programmable
Авариен сигнал:	1 x malfunctioning, 4 x user-configurable, max. 24 VDC/0.5 A, potential free contacts
Аналогови изходи:	Active 4 - 20 mA max. 500 Ohm load, standard 1, max. 8 (option)
Бр. потоци проби:	1, 2, 4 or 8
Гаранция:	24 месеца
Граница на откриваемост:	Calcium Hardness: ≤ 10 mg/L Total Alkalinity: ≤ 20 mg/L
Дренаж:	Atmospheric pressure, vented, min. Ø 32 mm
Захранване:	100 - 240 VAC, 50/60 Hz Max. power consumption: 120 VA
Измерване метод:	Acid-base titration (alkalinity only); Calmagite EDTA titration with LED dipping probe (combined)
Измерване, диапазон:	Ca: 10 - 100 mg/L CaCO_3 ; Alk: 20 - 500 mg/L CaCO_3
Калибриране:	N.A.
Клас на защита:	Protection class: Analyser cabinet: IP44 / Panel PC: IP65
Кювети за проба:	20 - 30 minutes 40 minutes (+ Total Hardness Ca)
Материал:	Hinged part: Thermoform ABS, door: PMMA Wall section: Galvanised steel, powder coated
Метод, име:	Titrimetric
Околна температура:	10 - 30 °C \pm 4 °C deviation at 5 - 95% relative humidity (non-condensing)
Параметър:	Calcium Hardness; Total Alkalinity
Проба, дебит:	100 - 300 mL/min
Проба, качество:	Maximum particle size 100 μm , < 0.1 g/L; Turbidity < 50 NTU
Проба: налягане:	By external overflow vessel
Размери (В x Ш x Д):	690 мм x 465 мм x 330 мм
Сертификати:	CE compliant / UL certified
Смущения:	Hardness: Some metal ions interfere by causing fading or indistinct end points or by stoichiometric consumption of EDTA. Suspended or colloidal organic matter also may interfere with the end point. Large amounts of colour and turbidity interferes. Fats, oil, proteins, surfactants and tar. Alkalinity: Soaps, oily matter, suspended solids or precipitates may coat the glass electrode and cause a sluggish response. Allow additional time between titrant additions to let the electrode come to equilibrium or clean the electrodes occasionally.
Тегло:	25 kg
Температура на проба:	10 - 30 °C